

BELL FLOORS 1951

DINING ROOM

MINWAX CLEAR } $\frac{1}{2}$
MINERAL SPIRITS } $\frac{1}{2}$

APPLY WITH BRUSH

5 MINUTES RUB STEEL

WOOL WITH

WIPE DRY, CLOTH.

DRY OVER NIGHT

APPLY WITH BRUCE CLEANER

AND PREEN EQUAL PARTS

AND THEN FINISH MACHIN
ONE HOUR LATER

WHITE PINE FLOOR.

EQUAL PARTS PREEN
APPLIED WITH.

AND BRUCE - STEEL

WOOL - WIPE CLEAN

CLOTH - POLISH

SEVERAL HOURS LATER